



Product Features & Benefits

- 3 Program cycles
- Fully insulated chamber and door as standard
- AktivPlus drain filter system for excellent wash results due to double filtered fresh water
- Fully electronic control system MIKE 2 with integrated infrared technology for simple and rapid service
- Stainless Steel wash and rinse arms for demanding use
- Floor clearance 150mm
- Rinse aid pump as standard
- Self-cleaning program for easy, hygienic cleaning of the wash chamber
- Integral Class 'A' air gap
- Wash tank pressed with coved corners
- Aqua Stop system with base drip tray for early intervention on any leaks in the machine

Optional Features

- Liquid Detergent Dosing Unit
- Air Concept heat recovery

MEIKO FV130.2			
TECHNICAL SPECIFICATIONS			
Water consumption L/basket		5.8	
Basket dimensions in mm		850 x 700	
Passing height in mm		740	
#Programme cycle in seconds		120/240/360	
A	Water Installation	Size	Hose ¾ "
		Flow pressure	1 bar -5 bar
		Temperature	Soft Hot water
		Water hardness	Max 53.4ppm
C	Sanitary Waste	Pump out drain	Hose ¾ "
E	Electrical connection	Three phase	3NPE 400V 50Hz, 15.0Kw

#For connection to cold water and/or short basket exchange times, the wash cycles may increase to achieve hygienic final rinse